
# Hawa Super 500 M




Hardware system for heavyweight metal sliding doors up to 500 kg (1100 lbs.). Suitable for use with sliding fire doors.

# Description

Hawa Super 500 M proven over the years for heavy metal doors. Very well suited for fire-retarding applications.

# Features of the Hawa Super 500 M

- Trolley with ball-bearing steel wheels
- Simple to installation
- Robust design
- Suitable for use with sliding fire doors
- Steel top bracket for bolting



Subject to modification. Metric specifications are exact. Inches are approximate.



## **Running tracks**

Caution: Hole positions vary			mm/inch	code
	Single running track, stainless steel WNR 1.4301/AISI 304	side- drilled	6000 (19'8 <sup>7</sup> / <sub>32</sub> ")	18033
			cut to size	18034
	Single running track, stainless steel WNR 1.4301/AISI 304	top- mounting flanges	6000 (19'8 <sup>7</sup> / <sub>32</sub> ")	18035
			cut to size	18036

#### **Bottom guide channels**

Caution: Hole positions vary		mm/inch	code
	Bottom guide channel, alu plain anodized,	6000 (19'8 <sup>7</sup> / <sub>32</sub> ")	14414
	predrilled, 20 x 20 mm $(\frac{55}{32}$ " x $\frac{25}{32}$ ")	cut to size	14415
	Bottom guide channel, alu plain anodized, predrilled, 31 x 28 mm $(1\frac{7}{32}$ x $1\frac{1}{8}$ ")	6000 (19'8 <sup>7</sup> / <sub>32</sub> ")	13688
		cut to size	13690
	Connecting bolt, Ø 6 x 40 m	13759	

#### **Accessories**

	code
Three-wheeled trolley, M12, with steel wheels	
Suspension plate, galvanized steel, with suspension bolt M12 and fixing screw	14480
Track stop, galvanized steel, to be drilled into the track	10595
Spring-loaded mortise-type door stop	10591
Screw-on rubber door stop	13114
Floor-mounted guide, plastic (the height can be shortened by the customers)	10509
Guide plastic 14 mm $(\frac{9}{16})$ with bolt M10	14474

# Order specifications

- Quantity of trolleys
- Quantity of suspension plates
- Quantity of track stops
- Type and length of running track
- Type and length of bottom guide channel
- Quantity and type of bottom guides
- Door width and door height

## Planning/installation

For planning and installation purposes, please use the installation drawing code 14587. (→ www.hawa.ch → Hawa Productfinder)